



Soft Flex

Crimping with Regular Crimping Pliers

Step 1: String a crimp tube and a clasp onto the wire. String the wire back through the crimp tube. Straighten the wires inside the crimp tube so that they lie side by side.

Step 2: Using the "crimper," gently compress the crimp tube, creating a divot.

Step 3: Using the "rounder," gently compress the crimp tube. Turn and repeat 3 times until it creates a round shape and equalizes the pressure. Cut off the excess wire at the base of the crimp.



Tying an *S-Knot* with Soft Flex® Beading Wire

